

SKID MARK GARAGE

2016 Camaro smoked rear reflector install guide.

Contents:

Smoked replacement Left & Right reflectors, 2 screws and 2 washers.

Tools required:

1 #2 Phillips screwdriver ** additional tools may be necessary if you decide to lower the mufflers to gain more room.

1. Using a lift or jack, raise the vehicle and secure with jack stands or similar.
2. Locate the existing red reflectors on the car and holding one of the new ones, you will be able to determine where the factory screw is on the back side of the existing red ones. You'll want to make a mental note here for the next step.
3. Reach up and around the exhaust tips where they exit the rear bumper, find the screw holding the existing reflector in place and remove it. Then using your finger or the screwdriver, you should be able to push from the back side of the reflector to get it to pop out.
4. Installation is reverse of removal.

**Removing the muffler/s is not necessary for this procedure, however if you have short chunky arms like I do, it may be easier to loosen the mounts a bit and let the mufflers tilt downwards or even flex the lower bumper portion a bit to access the screws. Or do like we did and invite a skinny friend over for a beer and put them to work.

S M G